

Covertex® wallcovering installation information

The surface of the wall must be dry, smooth, clean and primed. Covertex® is designed to cover stains and painted walls.

Adhesive and adhesion:

Please note that the paste must be rolled or brushed directly on to the wall when using our Covertex products.

Please use non-woven wallpaper glue for our heavy textile wall coverings. This is essential for subsequent work.



The strips of wallcovering cut to shape are then mounted directly on to the wall. Please spread the paste evenly over the surface of the wall so that it is covered uniformly.

A wallpaper edge roller is used to fix and press the textile on to the wall. Please do not work with hard brushes or scrapers!



Excess adhesive on the front of the textile must be carefully removed with a soft, dry and clean cloth. Otherwise, rubbing the printed textile will cause in damage.

The whole textile can be removed in one piece.